



## Light and fan controls



### Dimmers and switches

#### GRAFIK T\*†

- RRT-G25LW (250 W LED, 600 W INC/HAL/MLV dimmer)
- RRT-G5ANSW (5 A GRAFIK T neutral switch)
- RT-GRDW (GRAFIK T remote device)
- RRT-G5NEW (GRAFIK T phase selectable dimmer)

#### Maestro

- RRD-6CL-XX (150 W LED/CFL, 600 W INC/HAL/MLV dimmer)
- RRD-10D-XX (1000 W/VA INC/HAL/MLV dimmer)
- RRD-10ND-XX (150 W LED, 1000 W/VA INC/HAL/MLV neutral dimmer)
- RRD-8ANS-XX (8 A neutral switch)
- RRD-8S-DV-XX (dual-voltage 8 A switch)
- RRD-F6AN-DV-XX (dual-voltage 3-wire control dimmer)
- RRD-6NA-XX (phase-adaptive 150 W LED, 600 W/VA INC/HAL/MLV/ELV dimmer)
- RD-RD-XX (remote dimmer)
- RD-RS-XX (remote switch)
- RD-RD-277 (277 V remote dimmer)
- RD-RS-277 (277 V remote switch)
- RRD-3LD-XX (300 W lamp dimmer)

\* Available for use with Inclusive software only

\*\* Includes certificate for custom engraving

† Faceplate sold separately

### Hybrid keypads

#### GRAFIK T\*†

- RRT-GH2B (2-button, neutral optional, load optional)
- RRT-GH4B (4-button, neutral optional, load optional)
- RRT-GH5B (5-button, neutral optional, load optional)
- RRT-GH6B (6-button, neutral optional, load optional)

#### seeTouch\*\*

- RRD-H1RLD-XX (3-button, 2-button with raise/lower, dual group)
- RRD-H2RLD-XX (2-button with raise/lower, dual group)
- RRD-H3BSRL-XX (3-button spaced with raise/lower)
- RRD-H3S-XX (3-button favorite scene with raise/lower)
- RRD-H4S-XX (4-button favorite scene with raise/lower)
- RRD-H5BRL-XX (5-button with raise/lower)
- RRD-H6BRL-XX (6-button with raise/lower)

#### seeTouch C-L Neutral\*\*

- RRD-HN1RLD-XX (3-button, 2-button with raise/lower, dual group)
- RRD-HN2RLD-XX (2-button with raise/lower, dual group)
- RRD-HN3BSRL-XX (3-button spaced with raise/lower)
- RRD-HN3S-XX (3-button favorite scene with raise/lower)
- RRD-HN4S-XX (4-button favorite scene with raise/lower)
- RRD-HN5BRL-XX (5-button with raise/lower)
- RRD-HN6BRL-XX (6-button with raise/lower)